




UT8820

3/8 Capacity Pistol Grip Drill



Ref No	Part No	Description
1	732506	Motor Housing
2	732060	Valve Pin
3	732061	Exhaust Deflector
4	732062	Deflector Screw
5	732063	O-Ring
6	732064	Valve Stem
6A	732064A	O-Ring
7	732065	O-Ring (2)
8	732066	O-Ring
9	732067	Valve Bushing
10	732068	Trigger
11	732069	Retaining Ring
12	729012	Bearing
13	732507	Rear End Plate
14	732072	Pin

Ref No	Part No	Description
15	732508	Rotor
16	732074	Rotor Blade (4)
17	732075	Cylinder
18	732076	Front End Plate
19	732077	Ball Bearing
20	732078	Ring Gear
21	732079	Idler Gear (3)
22	732080	Idler Gear Plate
23	732081	Ball Bearing (2)
24	732082	Front Locking Adapter
25	731250	Drill Chuck (3/8") inc Key
26	729343	Name Plate Screw (2)
27	730229	Chuck Spacer
28	117701	Grub Screw M6*6